


**COMPONENTS LIST** – Panels and Parts pictures are contained in Installation Instructions.

**Ensure you have all parts before leaving your distributor or commencing installation.**

| PANELS               | DESCRIPTION  | NOTES   | QTY | CHECK |
|----------------------|--|---|-----|-------|
| <b>Floor</b>         | Dimensions of kennel. 70mm x 45mm joists with particleboard attached.  | Bottom plates of walls rest on the particleboard, with the cladding passing the particleboard edge.             | 1   |       |
| <b>Front</b>         | Small – 0.49m long<br>Medium – 0.64m long.<br>Large – 0.84m long.<br>Extra Large – 0.94m long.   | Opening for animal entry.<br>Cladding protrudes 20mm past bottom face of frame.<br>Weatherboard stops each end. | 1   |       |
| <b>Back</b>          | Small – 0.49m long.<br>Medium – 0.64m long.<br>Large – 0.84m long.<br>Extra Large – 0.94m long.  | Cladding protrudes 20mm past bottom face of frame.<br>Weatherboard stops each end.                              | 1   |       |
| <b>Sides</b>         | Small – 0.6m long, 0.42m high.<br>Medium – 0.8m long, 0.56m high.<br>Large – 0.9m long, 0.7m high.<br>Extra Large – 1.2m long, 0.84m high.       | Cladding protrudes 20mm past bottom face of frame.  | 2   |       |
| <b>Roofs</b>         | Small – 0.965m long, 0.35m high.<br>Medium – 1.15m long, 0.45m high.<br>Large – 1.335m long, 0.55m high.<br>Extra Large – 1.52m long, 0.6m high. | Steel sheeting with galvanised C section framing riveted.   | 2   |       |
| <b>PARTS</b>         |  |   |     |       |
| <b>Ridge top</b>     | Steel ridge capping folded both ends.  | Lengths as per roofs above.   | 1   |       |
| <b>FIXING SCREWS</b> |  |   |     |       |
| Wing Tip             | 40mm long Phillips head.   |                             |     |       |
| Particleboard        | 50mm long Phillips head.   |   | 0   |       |
| Tech                 | 20mm long 8mm Hex head.  |   | 12  |       |
|                      | 45mm long 8mm Hex head.  |   | 12  |       |
| Bugle                | 70mm long Allen key head.  |   | 16  |       |

**BEFORE COMMENCING INSTALLATION:**

1. Read all instructions thoroughly.
2. Ensure the site is level.
3. Identify and segregate all components.
4. Gather required tools.

**TOOLS REQUIRED:**

Variable speed drill with 3 bits – 8mm Hex socket, 5mm Allen key, and a Phillips head.  
 Tape Measure.  
 Safety glasses.  
 For site levelling, if required – Shovel, level, and a straight edge.



# INSTALLATION INSTRUCTIONS – TIMBER KENNEL

1. Ensure site is level and even. If not cut and fill. Use a straight edge and level to remove any uneven areas. Pack down firmly.
2. Place floor in desired position.
3. Position the front wall (Wall with opening for animal entry and weatherboard stops each end.) onto the desired end of the floor. Ensure the bottom plate of the pine wall frame rests on top of the floor, with the overhanging wall cladding firm/flush against the edge of the floor. The wall must be centred across the floor – 20mm overhang each side.
4. Place a side wall in the desired position square to and against the front wall. Ensure the overhang passes beside the particleboard floor, allowing the bottom plate of the wall to rest directly on the floor. Align the outermost points of the cladding on the side wall against the edge of the cladding stop on the front wall. Using two 70mm bugle screws evenly spaced, attach the side wall to the front wall through the corner wall studs.
5. Continue positioning and attaching the remaining walls as per steps 3 and 4 above.
6. After ensuring the bottom of the walls are suitably positioned on the floor, fix each wall to the floor using two 70mm bugle screws through the bottom plate of each wall into the flooring joists.
7. Position the roofs on top of the walls, ensuring they meet on the centre of the gable peak. The roof should protrude 60mm past the back, with the remaining length offering some protection to the entrance. Screw through the roof panel into the top of the gable using two 45mm tech screws at equal spacings in each panel on both ends. Screw through the roof panels into the top of the side walls using two 45mm tech screws in each roof positioned at equal spacings.
8. Fit the ridge top centrally on the join of the roof panels. Fix using six 20mm tech screws on each side, positioned into the last rib on each end and equally spaced along the roof length.